



Step 1: Create panel cut out, remove two M2.6x5mm screws and place EVA seal

